# Product data sheet

Rocker with lens and arrow symbols for KNX push-button 1-gang

| Reference number |
| --- |
| LC 101 KO5P 224 |

**1-gang rocker with lens and arrow symbols**

for JUNG HOME push-button 1-gang, battery-powered, ref.-no.: BT LS CD 1001
for KNX push-button 1-gang ref.-no.: LS CD 1071 1ST, LS CD 1091 1ST

**matt lacquered**

**Colour:**
orange

**Material:**
duroplastic lacquered

ALBRECHT JUNG GMBH & CO. KG
Volmestraße 1
58579 Schalksmühle

Telefon +49 (0) 23 55/80 60
Telefax +49 (0) 23 55/80 6189
E-Mail kundencenter@jung.de