


Product data sheet

Hotel push-button 230 V (insert), corridor unit



Reference number

534 KO5 EU D 230

Hotel push-button 230 V (insert), corridor unit

for hotel rocker corridor unit ref.-no.: .. CU KO5 D ..
with red LED lamp
with screwless terminals for rigid wires up to 2.5 mm²

screw fixing only, without claws

The corridor unit indicates the switch position of the room unit.

The push-button is used to activate the bell (e.g. triple-tone door signal, ref.-no. .. 567-G3 ..).

neutral conductor required

Version:

1-pole, 1-way NO contact with separate contacts for indicator light