

Product data sheet

Centre plate for Ackermann



Reference number

642 C

Centre plate for Ackermann, type 73642 C

reset button with lamp
reset button: green

for CD range
Thermoplastic (breakproof) high-gloss

Colour:
ivory

Material:
thermoplastic

P Individual colour printing possible