

Product data sheet

Centre plate for Ackermann



Reference number

642 D

Centre plate for Ackermann, type 73642 D

reset button with lamp

reset button: yellow

for CD range

Thermoplastic (breakproof) high-gloss

Colour:

ivory

Material:

thermoplastic

P Individual colour printing possible