

Product data sheet

1-gang push-button BCU, switch position



Reference number

8471.01 LED W

KNX push-button BCU, switch position

Depending on the version of the push-button BCU – 1-gang rocker or 2-gang rocker – centre plates are used with and without indication lights.

The “upper” or “lower” rockers can be controlled with the push-button with “neutral position”, while only the “lower” rocker can be pressed with the push-button with “switch position”. The push-button BCU can only function with an application program i.e. the push-button BCU consists of the device (hardware) and the application program (software).

Function: switching, dimming

LED: always ON, always OFF

KNX medium: TP 256

Can operate one group.

The status LED serves as orientation light or status indication.

Version:

1-gang