

Product data sheet

Rocker with lens and arrow symbols for KNX push-button 1-gang Rocker with lens and arrow symbols for KNX push-button 2-gang



Reference number

A 101 KO5P BF WWM

1-gang rocker with lens and arrow symbols
2-gang rocker with lens and arrow symbols

for JUNG HOME push-button 1-gang, battery-powered, ref.-no.: BT A 1001
for KNX push-button 1-gang ref.-no.: A 1071 1ST, A 1091 1ST
for JUNG HOME push-button 2-gang, battery-powered, ref.-no.: BT A 1002
for KNX push-button 2-gang ref.-no.: A 1072 1ST, A 1092 1ST

matt lacquered

Colour:
matt snow white

Material:
thermoplastic lacquered