

Product data sheet

Rocker with lens and arrow symbols for KNX push-button 1-gang



Reference number
A 101 KO5P MO
1-gang rocker with lens and arrow symbols for JUNG HOME push-button 1-gang, battery-powered, ref.-no.: BT A 1001 for KNX push-button 1-gang ref.-no.: A 1071 1ST, A 1091 1ST Duroplastic lacquered Colour: mocha Material: duroplastic lacquered