

# Product data sheet

Rocker with lens for KNX push-button 1-gang



## Reference number

GCR 101 KO5

## 1-gang rocker with lens

for JUNG HOME push-button 1-gang, battery-powered, ref.-no.: BT LS CD 1001  
for KNX push-button 1-gang ref.-no.: LS CD 1071 1ST, LS CD 1091 1ST

## Metal versions

**Colour:**  
chrome

**Material:**  
metal, chromium-plated

**P** Individual colour printing possible