

Product data sheet

Rocker with arrow symbols for KNX push-button 1-gang



Reference number

GCR 101 P

1-gang rocker with arrow symbols

for KNX push-button 1-gang ref.-no.: LS CD 1071 1ST, LS CD 1091 1ST, LS CD 1091 1TE

Metal versions

Colour:

chrome

Material:

metal, chromium-plated