

Product data sheet

Rocker with arrow symbols for KNX push-button 2-gang



Reference number

GCR 102 P

2-gang rocker with arrow symbols

for KNX push-button 2-gang ref.-no.: LS CD 1072 1ST, LS CD 1092 1ST, LS CD 1092 1TE

Metal versions

Colour:

chrome

Material:

metal, chromium-plated