

Product data sheet

Rocker with lens and arrow symbols for KNX push-button 2-gang



Reference number

GO 102 KO5P

2-gang rocker with lens and arrow symbols

for JUNG HOME push-button 2-gang, battery-powered, ref.-no.: BT LS CD 1002
for KNX push-button 2-gang ref.-no.: LS CD 1072 1ST, LS CD 1092 1ST

Metal versions

Colour:
gold-coloured

Material:
metal, gold-coloured PVD-coated