

Product data sheet

Rocker for KNX push-button 1-gang



Reference number
LC 101 214
1-gang rocker
for KNX push-button 1-gang ref.-no.: LS CD 1071 1ST, LS CD 1091 1ST, LS CD 1091 1TE
matt lacquered
Colour: céruléen clair
Material: duroplastic lacquered

P Individual colour printing possible