

Product data sheet

Rocker for KNX push-button 1-gang



Reference number
LC 101 217
1-gang rocker
for KNX push-button 1-gang ref.-no.: LS CD 1071 1ST, LS CD 1091 1ST, LS CD 1091 1TE
matt lacquered
Colour: vert anglais clair
Material: duroplastic lacquered



Individual colour printing possible