

Product data sheet

Rocker for KNX push-button 1-gang



Reference number

LC 101 247

1-gang rocker

for KNX push-button 1-gang ref.-no.: LS CD 1071 1ST, LS CD 1091 1ST, LS CD 1091 1TE

matt lacquered

Colour:
terre sienne brûlée 59

Material:
duroplastic lacquered



Individual colour printing possible