

Product data sheet

Rocker for KNX push-button 1-gang



Reference number

LC 101 258

1-gang rocker

for KNX push-button 1-gang ref.-no.: LS CD 1071 1ST, LS CD 1091 1ST, LS CD 1091 1TE

matt lacquered**Colour:**

terre sienne claire 59

Material:

duroplastic lacquered



Individual colour printing possible