

# Product data sheet

Rocker with lens for KNX push-button 1-gang



---

**Reference number**

---

LC 101 KO5 220

**1-gang rocker with lens**

for JUNG HOME push-button 1-gang, battery-powered, ref.-no.: BT LS CD 1001  
for KNX push-button 1-gang ref.-no.: LS CD 1071 1ST, LS CD 1091 1ST

**matt lacquered**

**Colour:**  
vert 31

**Material:**  
duroplastic lacquered

**P** Individual colour printing possible