

Product data sheet

Rocker with lens for KNX push-button 1-gang



Reference number

LC 101 KO5 256

1-gang rocker with lens

for JUNG HOME push-button 1-gang, battery-powered, ref.-no.: BT LS CD 1001
for KNX push-button 1-gang ref.-no.: LS CD 1071 1ST, LS CD 1091 1ST

matt lacquered

Colour:
bleu céruléen 59

Material:
duroplastic lacquered

P Individual colour printing possible