

# Product data sheet

Rocker with arrow symbols for KNX push-button 1-gang



---

**Reference number**

---

LC 101P 215

**1-gang rocker with arrow symbols**

for KNX push-button 1-gang ref.-no.: LS CD 1071 1ST, LS CD 1091 1ST, LS CD 1091 1TE

**matt lacquered**

**Colour:**

céruléen pale

**Material:**

duroplastic lacquered

---