


Product data sheet

Rocker with arrow symbols for KNX push-button 1-gang



Reference number
LC 101P 223
1-gang rocker with arrow symbols
for KNX push-button 1-gang ref.-no.: LS CD 1071 1ST, LS CD 1091 1ST, LS CD 1091 1TE
matt lacquered
Colour: ocre
Material: duroplastic lacquered