

# Product data sheet

Rocker with arrow symbols for KNX push-button 1-gang



## Reference number

LC 101P 241

## 1-gang rocker with arrow symbols

for KNX push-button 1-gang ref.-no.: LS CD 1071 1ST, LS CD 1091 1ST, LS CD 1091 1TE

**matt lacquered**

## Colour:

ombre naturelle 31

## Material:

duroplastic lacquered