

Product data sheet

Rocker with arrow symbols for KNX push-button 1-gang



Reference number

LC 101P 242

1-gang rocker with arrow symbols

for KNX push-button 1-gang ref.-no.: LS CD 1071 1ST, LS CD 1091 1ST, LS CD 1091 1TE

matt lacquered

Colour:

ombre naturelle moyenne

Material:

duroplastic lacquered