

Product data sheet

Rocker with lens for KNX push-button 2-gang



Reference number

LC 102 KO5 247

2-gang rocker with lens

for JUNG HOME push-button 2-gang, battery-powered, ref.-no.: BT LS CD 1002
for KNX push-button 2-gang ref.-no.: LS CD 1072 1ST, LS CD 1092 1ST

matt lacquered

Colour:
terre sienne brûlée 59

Material:
duroplastic lacquered

P Individual colour printing possible