


Product data sheet

Rocker with arrow symbols for KNX push-button 2-gang



Reference number
LC 102 P 207
2-gang rocker with arrow symbols
for KNX push-button 2-gang ref.-no.: LS CD 1072 1ST, LS CD 1092 1ST, LS CD 1092 1TE
matt lacquered
Colour: outramer moyen
Material: duroplastic lacquered