

# Product data sheet

Rocker with arrow symbols for KNX push-button 2-gang



## Reference number

LC 102 P 235

## 2-gang rocker with arrow symbols

for KNX push-button 2-gang ref.-no.: LS CD 1072 1ST, LS CD 1092 1ST, LS CD 1092 1TE

**matt lacquered**

**Colour:**  
terre sienne brûlée 31

**Material:**  
duroplastic lacquered