


Product data sheet

Rocker with arrow symbols for KNX push-button 2-gang



Reference number

LC 102 P 254

2-gang rocker with arrow symbols

for KNX push-button 2-gang ref.-no.: LS CD 1072 1ST, LS CD 1092 1ST, LS CD 1092 1TE

matt lacquered

Colour:

ocre jaune clair

Material:

duroplastic lacquered
