

Product data sheet

1-gang rocker for switch and push-button



Reference number

LC 990 207

1-gang rocker

for switch ref.-no.: 501 U, 502 U, 503 U, 506 U, 507 U, 501-20 U, 506-20 U, 507-20 U

for push-button ref.-no.: 531 U, 532 U, 533 U, 533-2 U

for multi push-button ref.-no.: 531-41 U

in combination with multi push-button no IP44 possible

Spare part:

holder plate ref.-no.: CD 90 HP

For illuminated inserts use rocker with lens ref.-no.: ..KO...

matt lacquered

Colour:

outremer moyen

Material:

duroplastic lacquered

P Individual colour printing possible