


Product data sheet

Rocker for KNX push-button 1-gang



Reference number
LS 101
1-gang rocker
for KNX push-button 1-gang ref.-no.: LS CD 1071 1ST, LS CD 1091 1ST, LS CD 1091 1TE
Duroplastic (scratch-proof) glossy
Colour: ivory
Material: duroplastic



Individual colour printing possible