

Product data sheet

Rocker with arrow symbols for KNX push-button 2-gang



Reference number

LS 102 P WW

2-gang rocker with arrow symbols

for KNX push-button 2-gang ref.-no.: LS CD 1072 1ST, LS CD 1092 1ST, LS CD 1092 1TE

Duroplastic (scratch-proof) glossy

Colour:

white

Material:

duroplastic