

Product data sheet

Centre plate for Ackermann



Reference number

LS 642 E

Centre plate for Ackermann, type 73642 E

reset buttons with lamp
reset buttons: yellow and green

for LS range
Thermoplastic (breakproof) high-gloss

Colour:
ivory

Material:
thermoplastic

P Individual colour printing possible