


Product data sheet

Pull cord push-button



Reference number

NRS AS 0834 ZT

Pull cord push-button

screw fixing only, without claws
without frame

An emergency call can be triggered in the bathroom/WC via an easily accessible pull cord. The pull cord push-button can also be installed in the middle of the room on the ceiling so that it is easily accessible for people in need of help. A red lamp on the switch signals that the emergency call has been triggered successfully.

pull cord ref.-no.: ZS-34 KO5S included

for AS and A ranges
Thermoplastic (breakproof) high-gloss

Colour:
ivory

Material:
thermoplastic

P Individual colour printing possible