

Product data sheet

Emergency signal



Reference number

NRS CD 0834 RM WW

Emergency signal

screw fixing only, without claws
without frame

The emergency signal can e.g. be installed outside next to the WC door or landing door. A triggered emergency call is signalled visually by a red LED and acoustically by a buzzer. Both signals can, if required, be changed from continuous light/continuous tone to flashing light/pulsing tone.

The floating relay contact (24 V / 2 A) can be used to trigger external signalling devices.

for CD range

Thermoplastic (breakproof) high-gloss

Colour:
white

Material:
thermoplastic