


Product data sheet

Reset button



Reference number

NRS LC 0834 AT 205

Reset button

screw fixing only, without claws

without frame

The reset button is installed next to the door in the same room as the pull cord push-button. The assisting personnel can reset the triggered call.

matt lacquered

Colour:

gris clair 31

Material:

duroplastic lacquered



Individual colour printing possible