


Product data sheet

Reset button



Reference number

NRS LC 0834 AT 217

Reset button

screw fixing only, without claws
without frame

The reset button is installed next to the door in the same room as the pull cord push-button. The assisting personnel can reset the triggered call.

matt lacquered

Colour:
vert anglais clair

Material:
duroplastic lacquered

P Individual colour printing possible