


# Product data sheet

## Reset button



### Reference number

NRS LC 0834 AT 242

### Reset button

screw fixing only, without claws  
without frame

The reset button is installed next to the door in the same room as the pull cord push-button. The assisting personnel can reset the triggered call.

**matt lacquered**

**Colour:**  
ombre naturelle moyenne

**Material:**  
duroplastic lacquered

**P** Individual colour printing possible