

Product data sheet

Emergency signal



Reference number

NRS LC 0834 RM 218

Emergency signal

screw fixing only, without claws
without frame

The emergency signal can e.g. be installed outside next to the WC door or landing door. A triggered emergency call is signalled visually by a red LED and acoustically by a buzzer. Both signals can, if required, be changed from continuous light/continuous tone to flashing light/pulsing tone.

The floating relay contact (24 V / 2 A) can be used to trigger external signalling devices.

matt lacquered

Colour:
vert anglais pale

Material:
duroplastic lacquered