


Product data sheet

Pull cord push-button



Reference number

NRS LC 0834 ZT 202

Pull cord push-button

screw fixing only, without claws
without frame

An emergency call can be triggered in the bathroom/WC via an easily accessible pull cord. The pull cord push-button can also be installed in the middle of the room on the ceiling so that it is easily accessible for people in need of help. A red lamp on the switch signals that the emergency call has been triggered successfully.

pull cord ref.-no.: ZS-34 KO5S included

matt lacquered

Colour:
gris foncé 31

Material:
duroplastic lacquered

P Individual colour printing possible