


Product data sheet

Reset button



Reference number

NRS LS 0834 AT SW

Reset button

screw fixing only, without claws
without frame

The reset button is installed next to the door in the same room as the pull cord push-button. The assisting personnel can reset the triggered call.

for LS range

Thermoplastic (breakproof) high-gloss

Colour:

black

Material:

thermoplastic



Individual colour printing possible