


Product data sheet

Reset button



Reference number

NRS LS 0834 AT WWM

Reset button

screw fixing only, without claws
without frame

The reset button is installed next to the door in the same room as the pull cord push-button. The assisting personnel can reset the triggered call.

for LS range
matt lacquered

Colour:
matt snow white

Material:
thermoplastic lacquered

P Individual colour printing possible